Engine hose lay

- #1 Crosslay discharge Pull from drivers side 200' 1-3/4 (**orange**) #2 Crosslay discharge Pull from officers side 200' 1-3/4" (**red**)
- #3 Crosslay discharge Pull from either side 200' 2-1/2" flat load (brown)



1 - 1st 100'flat load from either side, male on opposite side of truck where hose is to be pulled from. Leave minium of 18".



2 - third 50'with nozzle on top pull from bottom to opposite side of truck,



3 - bring hose over nozzle contune with load.



4 - connect to male on opposite side of truck



